

TRBOnet Enterprise/PLUS

MOTOTRBO Link

Deployment Guide

Last revised on 30 April 2025

USA Office

Neocom Software
150 South Pine Island Rd., Suite 300
Plantation, FL 33324, USA

Sales

EMEA: +44 203 608 0598
Americas: +1 872 222 8726
APAC: +61 28 607 8325

www.trbonet.com
info@trbonet.com

Contents

1	Introduction	2
1.1	About This Document	2
1.2	About TRBOnet.....	2
1.3	Contacts.....	2
2	System Components	3
2.1	TRBOnet Enterprise/Plus.....	3
2.2	IP Connection (Wireline Connection)	3
2.3	Wireless Connection (Control Stations)	3
3	System Description.....	4
3.1	System Restrictions	5
3.2	System Topologies	5
4	Configuring MOTOTRBO Equipment.....	7
4.1	Configuring a Standard Repeater.....	7
4.2	Configuring a Link Repeater	12
4.3	Configuring a Control Station	17
4.4	Configuring a Subscriber Radio	22
4.5	Configuring MOTOTRBO DDMS.....	30
4.6	Configuring MOTOTRBO MNIS	32
5	Configuring TRBOnet Enterprise	37
5.1	Configuring TRBOnet Server	37
5.2	Configuring TRBOnet Dispatch Console	50

1 Introduction

1.1 About This Document

The information in this guide is intended for administrators setting up evaluation and proof-of-concept deployments of MOTOTRBO Dispatch over IP solutions. This document describes the steps required to configure communication with a MOTOTRBO Link system.

For more comprehensive information on the Neocom TRBOnet family of radio network software tools, refer to the [Documentation section](#) of our web site.

1.2 About TRBOnet

TRBOnet is a suite of professional applications for MOTOTRBO digital two-way radio networks. TRBOnet manages voice and data communication paths across network endpoints. It provides a unified graphical dispatcher workbench interface for the entire range of workforce fleet management tasks.

1.3 Contacts

Region	Phone	Email & Support
EMEA	+44 203 608 0598	info@trbonet.com — general and commercial inquiries
Americas	+1 872 222 8726	support@trbonet.com — technical support
APAC	+61 28 607 8325	https://trbonet.com/kb/ — online knowledge base

2 System Components

2.1 TRBOnet Enterprise/Plus

The TRBOnet software consists of several modules which enable you to build enterprise dispatch solutions of different levels of complexity and redundancy. The first step in implementing the best solution is determining the topology for the customer's system; then identifying the combination of modules to implement the best customer solution.

2.2 IP Connection (Wireline Connection)

TRBOnet Server can be connected to a two-way radio system via an IP connection creating a direct communications path for all voice and data information between them. The topologies can be in the form of a LAN, WAN, or VLAN and/or any combination thereof.

2.3 Wireless Connection (Control Stations)

If TRBOnet Server doesn't have an IP connection to the radio system, it can be connected via control stations (also known as control radios or donor radios). Two control stations are required to transmit and receive voice and data to/from a repeater, that is, one control station per time slot.

3 System Description

The MOTOTRBO Link system mode consists of Standard repeaters, Link repeaters, Subscribers, Network Application Interface (NAI) and Remote Diagnostic and Alarm Control (RDAC) applications.

The role of the Standard Repeater in a MOTOTRBO Link configuration is essentially the same as a traditional repeater is in a conventional IP Site Connect configuration. The main function of the Standard repeater is to repeat calls received locally over-the-air (OTA) or calls received from the Link repeater on the LAN.

Usually, the site link could be microwave. In MOTOTRBO Link system mode, the role of the Link repeater is unique in that its site link essentially uses an OTA connectivity interface based on Digital Mobile Radio (DMR) protocols. The function of the Link repeater is to forward calls received from an adjacent backhaul site's Link repeater to the next site in the backhaul chain.

Based on location and function, backhaul sites have been defined into three categories:

Origin Site

The Origin Site is the first site in the backhaul chain of repeaters. There is only one Origin Site. Beacons flow towards the Origin Site so that they can be aggregated by the Proxy repeater that is also at the Origin Site.

Interim Site

The Interim Sites are the sites located between the Origin Site and the Terminating Sites in a backhaul chain of repeaters. The number of Interim Sites could be between one and seven. In Dedicated configurations, the Interim Sites must contain at least two Link Repeaters and an optional Standard Repeater.

Terminating Site

The Terminating Site is the site at the end of a backhaul chain.

The system may be deployed with between two and eight MOTOTRBO Link sites. There could be one NAI application and one RDAC connected to the system. Every MOTOTRBO Link site consists of either one or no Standard Repeater, and either one or two Link repeaters. The NAI application can be physically at any site. To monitor presence and alarm status remotely from the MOTOTRBO Link Repeaters, the RDAC must be connected to the Master repeater at the Origin Site.

Synchronization is the key to a MOTOTRBO Link system. It is the role of the Link repeaters to keep all the repeaters within the Backhaul chain synchronized. The GPIO Slot Timing Master Link Repeater at the Terminating Site transmits Beacon messages periodically while the system is idle. GPIO Slot Timing Master Link Repeaters at the Interim/Origin site synchronize to the transmissions. After adjusting the slot boundary, the GPIO Slot Timing Master Link Repeaters

toggle the General Purpose Input/Output (GPIO) pin of the Drop and Link repeater at the same site, then the Drop and Link repeater adjusts their slot boundary.

3.1 System Restrictions

According to the MOTOTRBO System Planner, a MOTOTRBO Link system does not support the following features:

- Transmit Interrupt
- Digital Telephone Patch
- Digital Voting
- Confirmed Group Data
- GPS Revert, Data Revert
- Enhanced/Scheduled GPS
- Repeater Call Monitoring (RCM)
- CSBK Data

Therefore, you need to take into account the above-listed restrictions when configuring your MOTOTRBO Link system.

3.2 System Topologies

There are two possible topologies when using the MOTOTRBO Link system with TRBOnet software.

3.2.1 IP Connection to Repeater

This topology is used when TRBOnet Server has an IP connection to the master repeater. Note the use of NAI Voice and NAI Data in this configuration.




Figure 1 IP Connection to the repeater

3.2.2 Connection via Control Stations

This topology is used when TRBOnet Server doesn't have an IP connection to the repeater. In this case, it can be connected via two control stations (also known as control radios or donor radios).




Figure 2 Wireless connection to the repeater

4 Configuring MOTOTRBO Equipment

This section describes how to configure MOTOTRBO equipment, such as repeaters, control stations and subscriber radios, using MOTOTRBO Customer Programming Software (CPS).

- Launch MOTOTRBO CPS.
- On the menu bar, select **View > Expert**.


4.1 Configuring a Standard Repeater

This section describes how to configure a Standard repeater located at the Origin (Interim, or Terminating) Site of a MOTOTRBO Link system.

- Connect your repeater to the PC via a programming cable (USB).
- Click the **Read** button on the toolbar.

4.1.1 General Settings


- In the **Set Categories** pane, select **General > General Settings**.



- In the right pane, specify the **Radio ID** of the repeater. This must be a unique Peer ID among the repeaters in a radio system and also not in conflict with any other third-party application Peer ID. The recommended range is from 1 to 255.

4.1.2 Accessories

- In the **Set Categories** pane, select **General > Accessories**.



- In the right pane, go to the **GPIO Physical Pins** section.


- **GPIO4**

From the drop-down list, select **Site Slot Sync Input**.

Note: For the Link (Peer) repeater on the same site, select **Site Slot Sync Output** for this GPIO. In addition, provide a wired connection between the pins # 16 (GND) and # 23 (SYNC) on the repeaters' rear panels.

4.1.3 Network

- In the **Set Categories** pane, select **General > Network**.



- In the right pane, specify the following parameters:

- **Radio IP**

This is the IP address used by the repeater to communicate with the PC (using the USB connection) and has to be unique. To avoid conflicts in case there are several stations connected with USB, you can change the third octet of the address.

Network Setting

If your radio system is on a private network, specify the following network parameters:

- **Ethernet IP**

This is the LAN address of the repeater that can be obtained from your network details; the last octet of the IP address must be unique for the system's local network.

- **Gateway IP**

This is the address of an upstream system (router). If a router exists, specify its LAN address here.

- **Gateway Netmask**

Set the Subnet Mask, for example, 255.255.255.0 or 255.255.0.0 depending on the subnet.


IP Repeater Programming

- **Enable**

Select this check box to provide the ability to remotely program the repeater.

4.1.4 Link Establishment

- In the **Set Categories** pane, select **General > Link Establishment**.



The screenshot shows the SLR 5500 configuration window with the 'Link Establishment' tab selected. The left pane shows the 'Set Categories' tree with 'Link Establishment' highlighted. The right pane shows the 'Network Setting' tab with the following parameters:

Parameter	Value
Link Type	Master
Authentication Key	99999
DNS	<input type="checkbox"/>
Master IP	10.10.102.131
Master DNS Address	None
Master UDP Port	50011
UDP Port	50011
Peer Firewall Open Timer (sec)	6


- In the right pane, specify the following parameters:
 - **Link Type**
From the drop-down list, select **Master**.
 - **Authentication Key**
Specify the authentication key that can optionally be used to access the repeater.

- **Master IP**
Enter the Ethernet IP address of the master repeater.
- **Master UDP Port**
Enter the UDP port number of the master repeater.
- **UDP Port**
Enter the UDP port number.

Note: Every repeater on the same site must have the same **UDP Port** value.

4.1.5 MOTOTRBO Link


- In the **Set Categories** pane, select **General > MOTOTRBO Link**.



- In the **MOTOTRBO Link** pane, specify the following parameters:
 - **Link Mode**
From the drop-down list, select **Dedicated Link**.
 - **Site Type**
From the drop-down list, select either **Origin Site**, **Interim Site**, or **Terminating Site**.
 - **Repeater Type**
From the drop-down list, select **Standard Repeater**.

4.1.6 Channel

- In the **Set Categories** pane, select **Zone/Channel Assignment**.
- In the right pane, click the plus sign button to add a zone.
- In the **Set Categories** pane, select the zone you have added.
- In the right pane, click the plus sign button and then choose **Type: Digital**.
- In the right pane, select the channel (for example, named Link S1) you have added and click the pencil button.



SLR 5500 > Zone > Zone1 > Zone Items > Link S1*

Set Categories

- Configuration*
 - Device Information
 - General
 - Zone/Channel Assignment
 - Zone

General

Channel Type: Digital

Channel Name: Link S1

Color Code: 1

Extended Range Direct Mode: Disabled

Inbound Color Code: 1

Outbound Color Code: 2

Network Application Interface Phone: ☐

System Controller Mode: No


IP Site Connect (Repeater): Slot 1 & Slot 2

Messaging Delay (ms): 60

Validation Results(1*) Warning Messages Search Results Help

Serial Number: 478IRW1074

- In the right pane, specify the following channel-related parameters.
 - Color Code**
Specify the color code for the repeater. Note that the color codes on the radios must match the color code of the repeater.
 - IP Site Connect**
From the drop-down-list, select **Slot 1 & Slot 2**.



SLR 5500 > Zone > Zone1 > Zone Items > Link S1*

Set Categories

- Configuration*
 - Device Information
 - General
 - Zone/Channel Assignment
 - Zone

General Enhanced GNSS RX/TX

Slot 1 Slot 2

RX/TX

RX

Frequency (MHz): 167.420000

Offset (MHz): 0.000000

TX

Frequency (MHz): 146.420000

Copy

Power Level: Low

TOT (sec): 60


Enhanced Channel Access: No

Validation Results(1*) Warning Messages(1*) Search Results Help

Serial Number: 478IRW1074

- In the **RX Frequency** box, enter the radio frequency the repeater will receive on.
- In the **TX Frequency** box, enter the radio frequency the repeater will transmit on.

Note: Make sure that the channel you have added is the first in the list of channels as the repeater will work on the channel which is on top of the list.



- Once you have finished configuring the desired repeater parameters, click the **Write** button on the toolbar.


4.2 Configuring a Link Repeater

This section describes how to configure a Link repeater located at the Origin or Terminating Site of a MOTOTRBO Link system.

For how to configure Link Repeaters on Interim Sites, see *MOTOTRBO System Planner (Release 2.10.5), 2.2.1.7 MOTOTRBO Link Mode*.

4.2.1 General Settings


- In the **Set Categories** pane, select **General > General Settings**.



- In the **General Settings** pane, specify the **Radio ID** of the repeater. This must be a unique Peer ID among the repeaters in a radio system and also not in conflict with any other third-party application Peer ID. The recommended range is from 1 to 255.

4.2.2 Accessories

- In the **Set Categories** pane, select **General > Accessories**.



- In the right pane, go to the **GPIO Physical Pins** section.


GPIO4

From the drop-down list, select **Site Slot Sync Output**.

Note: For the Standard (Master) repeater on the same site, select **Site Slot Sync Input** for this GPIO. In addition to an IP connection between the repeaters, provide a wired connection between the pins # 16 (GND) and # 23 (SYNC) on the repeaters' rear panels.

4.2.3 Network

- In the **Set Categories** pane, select **General > Network**.



- In the right pane, specify the following parameters:

- **Radio IP**

This is the IP address used by the repeater to communicate with the PC (using the USB connection) and has to be unique. To avoid conflicts in case there are several stations connected with USB, you can change the third octet of the address.

Network Setting

If your radio system is on a private network, specify the following network parameters:

- **Ethernet IP**

This is the LAN address of the repeater that can be obtained from your network details; the last octet of the IP address must be unique for the system's local network.

- **Gateway IP**

This is the address of an upstream system (router). If a router exists, specify its LAN address here.

- **Gateway Netmask**

Set the Subnet Mask, for example, 255.255.255.0 or 255.255.0.0 depending on the subnet.


IP Repeater Programming

- **Enable**

Select this check box to provide the ability to remotely program the repeater.

4.2.4 Link Establishment

- In the **Set Categories** pane, select **General > Link Establishment**.



- In the right pane, specify the following parameters:

- **Link Type**


From the drop-down list, select **Peer**.

- **Authentication Key**
Specify the authentication key that can optionally be used to access the repeater.
- **Master IP**
Enter the Ethernet IP address of the master repeater.
- **Master UDP Port**
Enter the UDP port number as that for the standard repeater on the same site.
- **UDP Port**
Enter the UDP port number.

Note: Repeaters under the same backhaul site must use the same port.

4.2.5 MOTOTRBO Link

- In the **Set Categories** pane, select **General > MOTOTRBO Link**.




- In the **MOTOTRBO Link** pane, specify the following parameters:
 - **Link Mode**
From the drop-down list, select **Dedicated Link**.
 - **Site Type**
From the drop-down list, select **Origin Site** or **Terminating Site**.
 - **Repeater Type**
From the drop-down list, select **Link Repeater**.
 - **GPIO Slot Timing Master**
Select this option so that this repeater is configured as the slot sync master.

4.2.6 Channel

- In the **Set Categories** pane, select **Zone/Channel Assignment**.
- In the right pane, click the plus sign button to add a zone.

- In the **Set Categories** pane, select the zone you have added.
- In the right pane, click the plus sign button and then choose **Type: Digital**.
- In the right pane, select the channel (for example, named Link S2) you have added and click the pencil button.




The screenshot shows the 'Set Categories' pane on the left with 'Zone' selected. The main pane displays the 'General' tab for 'Link S2'. The following parameters are highlighted with red circles:

- Color Code:** 1
- IP Site Connect (Repeater):** Slot 1 & Slot 2

Other visible parameters include: Channel Type (Digital), Channel Name (Link S2), Extended Range Direct Mode (Disabled), Inbound Color Code (1), Outbound Color Code (2), Network Application Interface Phone (unchecked), System Controller Mode (No), and Messaging Delay (ms) (60).

- In the **Channel** pane, specify the following channel-related parameters.
 - **Color Code**
Specify the color code for the repeater. Note that the color codes on the radios must match the color code of the repeater.
 - **IP Site Connect**
From the drop-down-list, select **Slot 1 & Slot 2**.



The screenshot shows the 'RX/TX' tab for 'Link S2'. The following parameters are highlighted with red circles:

- RX Frequency (MHz):** 419.972500
- TX Frequency (MHz):** 431.725000

Other visible parameters include: Slot 2 (unchecked), Offset (MHz) (0.000000), Power Level (Low), TOT (sec) (60), and Enhanced Channel Access (No).


- In the **RX Frequency** box, enter the radio frequency the repeater will receive on.
- In the **TX Frequency** box, enter the radio frequency the repeater will transmit on.

Note: Make sure that the channel you have added is the first in the list of channels as the repeater will work on the channel which is on top of the list.

4.3 Configuring a Control Station

This section describes how to configure the radio to be used as a control station in a MOTOTRBO Link system. Control stations are used in the scheme depicted in Figure 2.

- Connect your radio to the PC via a programming cable.
- Turn on the radio.
- Click the **Read** button on the toolbar.



4.3.1 General Settings

- In the **Set Categories** pane, select **General > General Settings**.
- In the right pane, specify the following:
 - **Radio ID**
Enter the Radio ID of the control station. The default value is **64250**.

Note: This value will then be used as the control station's **Radio ID** when connecting a control station to the TRBOnet Server. See section [5.1.2, Connecting a Control Station](#).

Control Station #1

Name: Control Station #1

Radio ID: 64250

IP Address: 192.168.98.2

Mode: IP Site Connect

System Identifier: Department 1

4.3.2 Network

- In the **Set Categories** pane, select **General > Network**.

871TPH7036 ▶ Network*

Set Categories

- Configuration*
 - Device Information
 - General
 - Welcome Bitmap
 - Language Packs
 - General Settings
 - Accessories
 - Control Buttons
 - Text Messages
 - Telemetry
 - Menu
 - Security
 - Network**
 - Voice Announcement

Services: Control Station IP Site Connect Bluetooth Bluetooth Serial Port Profile Data Routing USB HID Data Routing

Radio IP: 192.168.98.1

Accessory IP: 192.168.98.2

USB DNS-SD Interval: 90 sec

CAI Network: 12

CAI Group Network: 225

Protected Mode Control Station: ☐

Max TX PDU Size (bytes): 750

Telemetry UDP Port: 4008

Forward to PC: Via USB

Validation Results | Warning Messages | Search Results | Help

Serial Number: 871TPH7036

- In the right pane, specify the following parameters:
 - **Radio IP**
This is the IP address used by the radio to communicate with the PC (using the USB connection) and has to be unique. To avoid conflicts in case there are several stations connected with USB, you can change the third octet of the address.
 - **Accessory IP**
This is the IP address that is given to the PC by the radio that is connected to it.

Note: This value will then be used as the control station's **IP Address** when connecting a control station to the TRBOnet Server. See section [5.1.2, Connecting a Control Station](#).

Control Station #1

Name: Control Station #1

Radio ID: 64250

IP Address: 192.168.98.2

Mode: IP Site Connect

System Identifier: Department 1

- **Forward to PC**
From the drop-down list, select **Via USB**.

4.3.3 Contacts

- In the **Set Categories** pane, select **Contacts > Contacts**.
- In the right pane, click the plus sign button, then click **Digital** and choose the call type.

Sample_DP4801e > Contacts*

Set Categories

- Configuration*
 - Device Information
 - General
 - Job Tickets
 - Systems
 - Encoder
 - Decoder
 - Contacts
 - Police
 - Firemen
 - RX Group Lists

View by: ☒ By Name ☐ By Type ☐ Name Only

+

Contact Name	Call Type	Call ID
Firemen	Digital Calls-Group Call	20
Police	Digital Calls-Group Call	10


Validation Results(4*) Warning Messages Search Results Help

Serial Number: 871TRVP888

- Enter the **Contact Name** and **Call ID** for the contacts you have added.

4.3.4 RX Group Lists

- In the **Set Categories** pane, select **RX Group Lists > Digital RX Group List**.
- In the right pane, click the plus sign button and add the corresponding group list.





- In the left pane, select the group you have added.
- In the right pane, in the **Available** list select a group, or multiple groups using the SHIFT key, and click the **Add** button.

As a result, the group(s) will appear in the **Members** list.

4.3.5 Channel

- In the **Set Categories** pane, select **Zone/Channel Assignment**.
- In the right pane, click the plus sign button to add a zone.
- In the **Set Categories** pane, select the zone you have added.
- In the right pane, click the plus sign button and then choose **Type: Digital**.
- In the right pane, select the channel (for example, named Slot 1) you have added and click the pencil button.






- In the right pane, specify the following parameters:
 - **Color Code**
Enter the color code for the radio. Note that the color codes on the radios must match the color code of the repeater.
 - **Repeater/Time Slot**
Select the time slot of the repeater the radio operates on.
 - **Privacy**
Select this option to allow privacy on the channel.

Note: The **Privacy** option is available if the Basic or Enhanced Privacy Type has been selected in the Security section.
 - **Privacy Alias**
From the drop-down list, select the Key Alias.

Note: The **Privacy Alias** option is available if the Enhanced Privacy Type has been selected in the Security section. The same Key Alias must be used on all system nodes (repeaters and radios).
 - **Option Board**
Select this option to enable the option board capability on the channel. The option board must be installed and enabled in the radio otherwise this feature will not function.
 - **IP Site Connect**
Select this option to configure the channel as an IP Site Connect channel.

- **MOTOTRBO Link**
Ensure that this option is selected.



- In the **RX Frequency** box, specify the radio frequency the radio will receive on.
- In the **TX Frequency** box, specify the radio frequency the radio will transmit on.

Note: The RX and TX frequencies of the radio must be the opposite to the RX and TX frequencies of the repeater the radio operates on. In other words, the RX frequency of the repeater must be the same as the TX frequency of the radio; the TX frequency of the repeater must be the same as the RX frequency of the radio.

- **RX Group List**
Select the Group list you have specified in section [4.3.4, RX Group Lists](#).
- **TX Contact Name**
Select the contact to which a call will be initiated on the channel when pressing the PTT button. The contact is selected from the Contact list you have created in section [4.3.3, Contacts](#).


- Once you have finished configuring the desired radio parameters, click the **Write** button on the toolbar.

4.4 Configuring a Subscriber Radio

This section describes how to configure a subscriber radio to be used in a MOTOTRBO Link system.

- Connect your radio to the PC via a programming cable.
- Turn on the radio.

- Click the **Read** button on the toolbar.




4.4.1 General Settings

- In the **Set Categories** pane, select **General > General Settings**.
- In the right pane, specify the following parameters:
 - **Radio ID**
Enter the Radio ID of the radio. This ID is used by other radios to contact this radio, for instance, communicating via a private call or text message.
 - **GNSS**
Select this check box to track the location of the radio if the radio is equipped with a GPS module.
 - **Private calls**
Select this check box to enable the initiation of a Private Call on a digital channel. When disabled, a prohibit tone will sound when the user tries to initiate a Private Call.

4.4.2 Network

- In the **Set Categories** pane, select **General > Network**.




- In the right pane, specify the following parameters.
 - **Radio IP**
This is the IP address used by the radio to communicate with the PC (using the USB connection) and has to be unique. To avoid conflicts in case there are several stations connected with USB, you can change the third octet of the address.
 - **Forward to PC**
From the drop-down list, select **Disabled**.
 - **ARS Radio ID**
Specify the Radio ID of the ARS server.
 - **TMS Radio ID**
Specify the Radio ID of the TMS server.

Note: The **ARS Radio ID** and **TMS Radio ID** must be the same as **MNIS Application ID** (see section [4.6, Configuring MOTOTRBO MNIS](#)), or **Radio ID** in the Control Station settings if the control station is connected to TRBOnet Server via USB (see section [5.1.2, Adding a Control Station](#)).

The recommended value is **64250** for both parameters.

4.4.3 Contacts


- In the **Set Categories** pane, select **Contacts > Contacts**.
- In the right pane, click the plus sign button, then click **Digital** and choose the call type.



- Enter the **Contact Name** and **Call ID** for the contacts you have added.

4.4.4 RX Group Lists

- In the left pane, select **RX Group Lists > Digital**. Right-click it, and choose **Add > RX Group List**.





- In the left pane, select the group you have added.
- In the right pane, in the **Available** list select a group, or multiple groups using the SHIFT key, and click the **Add** button.
As a result, the group(s) will appear in the **Members** list.

4.4.5 Channels

- In the **Set Categories** pane, select **Zone/Channel Assignment**.
- In the right pane, click the plus sign button to add a zone.
- In the **Set Categories** pane, select the zone you have added.

- In the right pane, click the plus sign button and then choose **Type: Digital**.
- In the right pane, select the channel (for example, named Slot 1) you have added and click the pencil button.

Note: You'll have to create two digital channels for the repeater's slots 1 and 2.



- In the right pane, specify the following parameters:
 - **Scan/Roam List**
Select the Roam list you have specified in section [4.4.6, Roam Lists](#).


- **Color Code**
Enter the color code for the radio. Note that the color codes on the radios must match the color code of the repeater.
- **Repeater/Time Slot**
Select one of the repeater time slots.
- **Phone System**
Select the phone system you have specified in section [4.4.7, Phone System](#).
- **ARS**
Select **On System Change** to provide the automated registration for the radio.
- **Privacy**
Select this option to allow privacy on the channel.

Note: The **Privacy** option is available if the Basic or Enhanced Privacy Type has been selected in the Security section.

- **Privacy Alias**
From the drop-down list, select the Key Alias.

Note: The **Privacy Alias** option is available if the Enhanced Privacy Type has been selected in the Security section. The same Key Alias must be used on all system nodes (repeaters and radios).

- **Option Board**
Select this option to enable the option board capability on the channel. The option board must be installed and enabled in the radio otherwise this feature will not function.
- **IP Site Connect**
Select this option to configure the channel as an IP Site Connect channel. If this option is selected, you can add the channel to a Roam List (see section [4.4.6, Roam Lists](#)).
- **MOTOTRBO Link**
Ensure that this option is selected.



- In the **RX Frequency** box, specify the radio frequency the radio will receive on.
- In the **TX Frequency** box, specify the radio frequency the radio will transmit on.


Note: The RX and TX frequencies of the radio must be the opposite to the RX and TX frequencies of the repeater. In other words, the RX frequency of the repeater must be the same as the TX frequency of the radio; the TX frequency of the repeater must be the same as the RX frequency of the radio.

- **RX Group List**
Select the Group list you have specified in section [4.4.4, RX Group Lists](#).
- **TX Contact Name**
Select the contact to which a call will be initiated on the channel when pressing the PTT button. The contact is selected from the Contact list you have created in section [4.4.3, Contacts](#).

4.4.6 Roam Lists

Roaming will allow using the radio on different sites of a MOTOTRBO Link system.

- In the **Set Categories** pane, select **Scan Lists > Roam List**.
- In the right pane, click the plus sign button and add the corresponding roam list.



- In the left pane, select the roam list you have added.
- In the right pane, in the **Available** list select a channel, or multiple channels using the SHIFT key, and click the **Add** button.

As a result, the channel(s) will appear in the **Members** list.


- **RSSI Threshold (dBm)**

If the RSSI measurement of the site is above the specified RSSI Threshold, then the radio will remain on that site and not roam.

4.5 Configuring MOTOTRBO DDMS

The DDMS, or Device Discovery and Mobility Service is a service for tracking the presence of radio subscribers in the radio network and transmitting the data to the server. The schemes using DDMS are depicted in Figure 1. This section describes how to configure and run MOTOTRBO DDMS service using MOTOTRBO DDMS Administrative Client.


- Launch MOTOTRBO DDMS Administrative Client.
- In the left pane, select **Watcher Settings**.




■ PortWatcher

This is the port number for listening TRBOnet Server requests.

Note: This value will be used when configuring DDMS parameters in section [5.1.1.3, DDMS Service](#), **Service port**.




- In the left pane, select **Authentication Server Settings**.




- **AuthenticationServerIP**
This is the authentication server IP address.
- **AuthenticationServerPort**
This is the authentication server port number.

Note: These values will be used when configuring DDMS parameters in section [5.1.1.3, DDMS Service](#), **Service IP Address** and **Authentication Port**, respectively.




- Once you have finished configuring the desired DDMS parameters, click the **Start** button on the toolbar.



4.6 Configuring MOTOTRBO MNIS


The MNIS, or Motorola Network Interface Service, is a Windows application which acts as a data gateway between the data applications and the radio system. Data messages are routed through the MNIS. The topologies using MNIS are depicted in Figure 1. This section describes how to configure and run MOTOTRBO MNIS service using MNIS Configuration Utility.

- Launch MNIS Configuration Utility.
- In the left pane, select **General**.



- **System Operation Mode**
From the drop-down list, select **Conventional**.
- **MNIS Application ID**
This is an individual ID that uniquely identifies the MNIS application in the radio system. The recommended value is **64250**.

Note: This is the ID that TRBOnet Server uses as its **Radio ID** when connecting a master repeater.
- **MNIS IP Address**
It is recommended that the value of **172.16.10.1** is used unless there are conflicts with other network interfaces on the PC.
- **Tunnel IP Address**
This is the IP Address used by the MNIS to communicate with TRBOnet Enterprise (see [5.1.1.4, MNIS Data Service, IP Address](#)).



MNIS data service


☒ Use Data Gateway

☒ Service is on a local host

IP Address: 172.16.10.2

☒ Control port: 5000

- In the left pane, select **Conventional > Domain 1**.



MNIS Data Gateway Configuration Utility *

Configuration View Edit Service Help

Domain 1

Master IP Address 10.10.102.131

Master UDP Port 50011

MNIS LE Port ☒ Automatically Assigned ☐ Manually Assigned None

Authentication Key 0

SFR Mode ☐

MOTOTRBO Link ☒

Repeater Slot 1

Enable ☒

Revert Channel ☐

Security Setting None

Security Alias

Group List None


Repeater Slot 2

Enable ☒

Revert Channel ☐

- **Master IP Address**
Enter the Ethernet IP address of the master repeater.
- **Master UDP Port**
Enter the UDP port number of the master repeater.
- **Authentication Key**
Enter the master repeater's authentication key (if any).
- **MOTOTRBO Link**
Make sure this option is selected.
- **Repeater Slot 1 Enable/Repeater Slot 2 Enable**
Select these options so that MNIS will be able to send or receive data over these slots.

- In the left pane, select **Advanced**.




- **Compressed UDP Data Header**

From the drop-down list, select the type of compression protocol used for the UDP Data Header (None, MSI, DMR). It is recommended selecting **MSI**. Note that the same type must be set on all subscriber radio channels (*CPS>Channels>Compressed UDP Data Header*).

- **MNIS LE ID > Manually Assigned**

Enter a unique Peer ID among the repeaters in a radio system.

- In the left pane, select **Network**.



Device Discovery and Mobile Service

- **Server Address**

This is the IP address of the MOTOTRBO Device Discovery and Mobility Service (DDMS). The recommended value is **127.0.0.1** if both DDMS and MNIS reside on the same PC.


- **Watcher Port**

This is the port number on the MOTOTRBO Device Discovery and Mobility Service (DDMS) server to which the Watcher requests should be sent.

MNIS Control Interface

- **MNIS Control Interface TCP Port**

This is the Transmission Control Protocol (TCP) port for the MNIS Control Interface server. This value is used when connecting TRBOnet Server to MNIS Service (see [5.1.1.4, MNIS Data Service, Control port](#)).




Once you have finished configuring the desired MNIS parameters, do the following:

- Click the **Save** button on the toolbar.



- On the **Configuration** menu, click **Set as Active Configuration**.



- Click the **Start** button on the toolbar.



5 Configuring TRBOnet Enterprise

This section describes how to configure TRBOnet Enterprise software. By properly configuring TRBOnet Server and TRBOnet Dispatch Console, you will be able to utilize the full capabilities of your IP Site Connect system.

5.1 Configuring TRBOnet Server

To start TRBOnet Server, click the corresponding shortcut on the desktop, or click **Start > All Programs > Neocom Software > TRBOnet Server x.x**


For instructions on how to configure TRBOnet Server's Database, Service, Network parameters, etc., refer to *TRBOnet Enterprise Quick Start Guide*.

5.1.1 Adding a Master Repeater


This section describes how to configure TRBOnet Server for communication with the master repeater of a MOTOTRBO Link system.

Note: Only the Master repeater needs to be added to TRBOnet Server.

- In the **Radio Systems** pane, click **Add**.
Or, in the **Configuration** pane, right-click **Radio Systems**.
- In the drop-down menu, click **Add MOTOTRBO System**.



In the **Repeater** pane, specify the connection parameters. To ensure your connection parameters match the actual configuration of your radio network, you may need to use Motorola CPS to determine the values. Contact your radio network administrator, if you do not have this information.



- **System Name**
Enter a name for the repeater. This name will be displayed in the Dispatch Console.
- **TRBOnet Peer ID**
Enter a Peer ID for TRBOnet Server. The Peer ID must be unique among the repeaters in the radio system.
- **TRBOnet Radio ID**
Enter the Radio ID of the gateway for voice and data in the radio system. This Radio ID is used as **ARS Radio ID** and **TMS Radio ID** in the Network settings of subscriber radios (see sections [4.4, Configuring a Subscriber Radio](#), [4.4.2, Network](#)). The default value is **64250**.
- **TRBOnet Local Port**
Enter the port number on the TRBOnet Server computer that will be used by TRBOnet Server to establish a connection to the repeater. Use unique port numbers for each repeater connection if there are several repeaters connected.

Master Repeater Connection Information

- **IP Address**
Enter the Ethernet IP address of the master repeater.

Note: This value is programmed for a repeater via MOTOTRBO CPS, in *Link Establishment>Master IP*. See section [4.1.4](#).

- **UDP Port**
Enter the UDP port number of the master repeater.

Note: This value is programmed for a repeater via MOTOTRBO CPS, in *Link Establishment>Master UDP Port*. See section [4.1.4](#).

- **Authentication Key**

Enter the repeater's authentication key (if any).

Note: This value is programmed for a repeater via MOTOTRBO CPS, in *Link Establishment>Authentication Key*. See section [4.1.4](#).

- **System Type**

From the drop-down list, select **IP Site Connect**.

- **Test**

Click this button to check the connection to your master repeater. If the test is successful, you'll see the information about the repeater you are connected to, such as the serial number, firmware version, and other relevant information.

- **System Identifier**

Enter the system identifier. Note that the system identifier should be the same for all control stations and repeaters used in the same radio system.


- **Use NAI Voice, Use NAI Data (MNIS and DDMS)**

Select these options. Note that the Network Application Interface Voice and Network Application Interface Data features must be enabled on the repeaters.

Click **Apply** after entering all the required values. A confirmation dialog will appear, prompting you to save the configuration and restart the TRBOnet Server service. You can also restart the service manually.

5.1.1.1 Advanced Settings

- In the **Configuration** pane, under the corresponding **Repeater**, select **Advanced settings**.



- In the **Advanced Settings** pane, specify the following repeater-related advanced settings:

Call Hangtime (ms):

- **Group Call**

This value sets the duration the repeater reserves the channel after the end of a group call transmission. During this time, only members of the group that the channel is reserved for can transmit.

- **Private Call**

This value sets the duration a radio keeps the private call setup after a user releases the PTT button. This is to avoid setting up the call again each time a user presses the PTT button to transmit. During this time, other radios can still transmit since the channel is essentially idle. After the hang timer expires, the radio transmits using the *TX Contact Name* parameter specified for this channel in MOTOTRBO CPS.

- **Emergency Call**

This value sets the duration the repeater reserves the channel after the end of an emergency call transmission. During this time, only members of the Group that the channel is reserved for can transmit.

Note: The values of the above three parameters must be taken from the corresponding parameter values programmed for the repeater via MOTOTRBO CPS in *General Settings*.

■ TX Preamble


Enter the value of the TX Preamble. The TX Preamble is a string of bits added in front of a data or control message (Text Messaging, Location Messaging, Registration, Radio Check, Private Call, and other message types) before transmission. The acceptable range is 0 - 8640 ms. The recommended value is 120 ms.

■ TX Timeout

Enter the time, in seconds, to be used as a voice session limit. When the dispatcher starts any voice session in the Dispatch Console, transmission will be interrupted after this TX Timeout expires.

5.1.1.2 Privacy

- In the **Configuration** pane, under the corresponding **Repeater**, select **Privacy**.



- In the **Privacy** pane, specify the following privacy-related settings:
 - **Privacy Type**
From the drop-down list, select one of the privacy types: **None**, **Basic**, or **Enhanced**.
 - **Basic Privacy Key ID**
Enter the Privacy Key ID available for the **Basic** privacy type.
 - **Enhanced Privacy Keys**
Here you add enhanced privacy keys when the **Enhanced** privacy type is selected.
 - Click **Add** and specify the required **Algorithm**, **ID**, **Name**, and **Value** for the privacy key being added.


✓ Algorithm

From the drop-down list, select one of the enhanced algorithms if you are going to use additional encryption.

5.1.1.3 DDMS Service

The DDMS, or Device Discovery and Mobility Service is a service for tracking the presence of radio subscribers in the radio network and transmitting the data to the server.

- In the **Configuration** pane, under the corresponding **Repeater**, select **DDMS service**.



Configuration

- Service
- Network
- Redundancy
- Remote Access Restriction
- Database
- Storage Locations
- File Formats
- Reports
- Service Management
- Advanced Settings
- Geocoding Servers
- Radio Systems
 - Services
 - Repeater #1
 - Advanced Settings
 - Privacy
 - DDMS service**
 - Advanced Settings
 - MNIS data service
 - Slot #1
 - Slot #2
 - Local Slots

DDMS service

☒ Use DDMS service

Local port:

Service IP Address:

Service port:

Authentication Port:

Redundant services:

		Service IP Address	Service port	Local port
1	<input checked="" type="checkbox"/>	10.10.101.207	3000	0

- In the **DDMS service** pane, specify the following DDMS service-related settings:
 - **Use DDMS service**
Select this option to enable the DDMS service for the server.
 - **Local Port**
Enter the number of the local port to be used on a PC with TRBOnet Dispatch Software for DDMS service.
 - **Service IP Address**
Enter the IP Address of the PC with the DDMS service installed and running.
 - **Service port**
Enter the service port number.

Note: This value is programmed for a DDMS service via MOTOTRBO DDMS Administrative Client, in *Interfaces>Watcher Settings>PortWatcher*.

■ Authentication Port

Enter the authentication server port number.

Note: This value is programmed for a DDMS service via MOTOTRBO DDMS Administrative Client, in *Interfaces>Authentication Server Settings>AuthenticationServerPort*.

■ Redundant services


Here you see the list of redundant DDMS services for failover purposes.

- Click **Add** and specify the required parameters for the DDMS service being added.
- Click **Test** to test if the selected DDMS service is available.
- Use the **Up** (▲) and **Down** (▼) buttons to move a selected DDMS service up and down in the priority list of DDMS services.

5.1.1.4 MNIS Data Service

MNIS, or Motorola Network Interface Service, is a Windows application which acts as a data gateway between the data applications and the radio system. Data messages are routed through MNIS.

- In the **Configuration** pane, under the corresponding **Repeater**, select **MNIS data service**.



- In the **MNIS data service** pane, specify the following MNIS data service-related settings:
 - **Use Data Gateway**
Select this option to enable the MNIS data service for the server.

- **Service is on a local host**

Select this option if the MNIS data service will be used on the local PC.

- **IP Address**

Enter the IP Address used by the MNIS to communicate with the PC.

Note: This value is programmed for a MNIS data service via MOTOTRBO MNIS Configuration Utility, and can be retrieved from
General>Tunnel Network>Tunnel IP Address.

- **Control port**

Enter the number for the MNIS control port.

Note: This value is programmed for a MNIS data service via MOTOTRBO MNIS Configuration Utility, in
Advanced>Network>MNIS Control Interface TCP Port.

- **MNIS Service**

Select this option, and from the drop-down list select the available MNIS service.


- **Redundant services**

Here you see the list of redundant MNIS data services for failover purposes.

- Click **Add** and specify the required parameters for the MNIS data service being added.
- Click **Test** to test if the selected MNIS data service is available.
- Use the **Up** (▲) and **Down** (▼) buttons to move a selected MNIS data service up and down in the priority list of MNIS data services.

5.1.1.5 Slots

- In the **Configuration** pane, under the corresponding **Repeater**, select **Slot #1** or **Slot #2**.



- In the **Slot #1** (or **Slot #2**) pane, specify the following slot-related parameters:

Note: Some of the features may not be applicable. See section [3.1, System Restrictions](#).

- **Name**
Enter a name for the slot. This name will be displayed in the Dispatch Console.
- **Messaging Delay**
From the drop-down list, select the inter-repeater messaging delay based on the IP network configuration.
 - Normal
The inter-repeater messaging delay is 60 ms.
 - High
The inter-repeater messaging delay is 90 ms.
- **Use slot for RX data only (GPS Revert or Data Revert)**
Select this option to configure the slot so that it will only receive data, thus having no transmission capability.
- **Use Privacy**
Select this option to use Privacy for the slot.

Note: This option is available only if the **Basic** or **Enhanced** Privacy Type have been selected in Repeater's [Privacy](#) settings.

- **Privacy Key**

From the drop-down list, select the privacy key.

Note: This option is available only if the **Enhanced** Privacy Type has been selected in Repeater's [Privacy](#) settings).

- **Allow interruption**

Select this option to allow interrupting dispatcher transmissions by radios that are Transmit Interrupt capable.

- **Always transmit when the PTT is pressed ("Impolite" channel access)**

Select this option so that when the PTT button is pressed, the dispatcher will start transmitting regardless of whether the channel is free or not (that is any transmission in progress will be interrupted).

- **Private Call Confirmed**

Select this option to set Private calls on the current slot as confirmed. By default, Private calls are unconfirmed.

- **Emergency Alarm Ack**

Select this option so that the Dispatch Console is allowed to acknowledge an emergency alarm received via this slot.


- **Emergency Call/Alarm Indication**

Select this option so that audio and visual indication is given for an emergency call/emergency alarm received via this slot.

5.1.2 Adding a Control Station

This section describes how to configure TRBOnet Server for communication with a control station in a MOTOTRBO Link system.

- In the **Digital Systems** pane, click **Add**.
Or, in the **Configuration** pane, right-click **Digital Systems**.
- In the drop-down menu, click **Add Control Station**.



- In the **Control Station** pane, specify the following control station-related parameters:

- **Name**

Enter a name for the control station. This name will be displayed in the Dispatch Console.

- **Radio ID**

This is the Radio ID of the radio unit connected as a control station.

Note: This box is populated automatically once you have successfully tested the control station by clicking the **Test** button.

- **IP Address**

Enter, or select from the list, the IP Address of the control station network interface.

Note: This value can be taken from the radio's configuration in MOTOTRBO CPS, in *Network>Accessory IP*.

- **Test**

Click this button to check the connection to the control station. If the test is successful, you'll see the information on the control station you are connected to, such as radio ID, serial number, firmware version, and other relevant information.


- **Mode**

From the drop-down list, select **IP Site Connect**.

- **System Identifier**
Enter the system identifier. Note that the system identifier should be the same for all control stations and repeaters used in the same radio system.
- **Use the radio for RX data only (GPS Revert or Data Revert)**
Select this option to configure the radio channel so that it will only receive data, thus having no transmission capability.
- **Playback device**
From the drop-down list, select the playback device on the PC that will be used to transfer audio to the control station.
- **Recorder device**
From the drop-down list, select the recording device on the PC that will be used to audio from the control station via a line-in jack connection.
- Click **Apply** after entering all the required values. A confirmation dialog will appear, prompting you to save the configuration and restart the TRBOnet Server service. You can also restart the service manually.

5.1.2.1 Advanced Settings

- In the **Configuration** pane, under the corresponding **Control Station**, select **Advanced Settings**.



- In the **Advanced Settings** pane, specify the following control station-related advanced settings:
 - **Automatically reset alarm mode**
Select this option to reset alarm mode on the control station radio automatically. It is recommended to enable this option.

- **Automatically handle call alert**
Select this option to automatically redirect call alerts from the control station radio to the Dispatch Console.
- **Emergency Call/Alarm indication**
Select this option so that audio and visual indication is given by the control station radio when an Emergency Call/Emergency Alarm is received.
- **Use front microphone**
Select this option to use the speaker microphone on the front of the radio.
- **Always transmit when the PTT is pressed ("Impolite" channel access)**
Select this option so that when the PTT button is pressed, the radio will start transmitting regardless of whether the channel is free or not (that is any transmission in progress will be interrupted).
- **Use serial port for PTT device**
Select this option to use a remote control of the PTT button via the serial port of the PC, and select the serial port from the drop-down list.
- **TX Timeout**
Enter the time, in seconds, to be used as a voice session limit. When a dispatcher starts any voice session in the Dispatch Console, the ongoing transmission will be interrupted after this TX Timeout expires.
- **Mic delay time**
Select this option and specify the time, in milliseconds, to be used as a delay time interval between pushing the PTT and enabling the microphone.
 - **Roger beep**
Select this option to play a beep sound for the time interval until the microphone is enabled. Click the ellipsis button (...) on the right and locate the desired sound file (WAV).
- **Signaling system**
From the drop-down list, select the signaling system.
- **Allow CSBK Data**
Select this option so that GPS data is sent in a single CSBK.

5.2 Configuring TRBOnet Dispatch Console


To start TRBOnet Server, click the corresponding shortcut on the desktop, or click **Start > All Programs > Neocom Software > TRBOnet Dispatch x.x**

The dialog box will appear prompting you to enter the TRBOnet Server IP address, User Name, and Password. The default Administrator credentials are **admin** for the login and **admin** for the password.

For a more detailed information on how to use TRBOnet Dispatch Console, refer to *TRBOnet Enterprise User Manual*.

5.2.1 Registering Radio Groups

Go to **Administration (1)**, **Radio Group (2)** to add/edit/delete Radio Groups in the system.




- Click **Add (3)** to add a radio group to the system:
- In the dialog box that appears, specify the **Name** and **Group ID (Radio ID)** of the group you are adding.

Note: Ensure that the radio group(s) created in the Dispatch Console are present in the radio's RX Group List (see section [4.4.4, RX Group Lists](#)).

5.2.2 Registering Radios

Go to **Administration** (1), **Radios** (2) to add/edit/delete Radios in the system.



- Click **Add MOTOTRBO Radio** (3) to add a new radio.
- In the dialog box that appears, specify the **Radio Name**, **Radio ID**, **Radio Groups**, and **Home Group** to which the radio belongs.